


# TempTron 607 Ver L450



## Digital input connectors

DIG 1	
DIG 2	Water count
DIG 3	Feed count
DIG 4	


## Analog input connectors

IN 1	Temperature sensor 1
IN 2	Temperature sensor 2
IN 3	Temperature sensor 3
IN 4	Temperature sensor 4
IN 5	Pressure sensor
IN 6	Humidity sensor

## Analog outputs

Out 1	Speed fan out
Out 2	Inlet out

### Relay connections



### Relay connections

<b>Relay 1</b>	<b>Alarm</b>
<b>Relay 2</b>	<b>Heater</b>
<b>Relay 3</b>	<b>Speed fan baffle</b>
<b>Relay 4</b>	<b>Fan1 Group</b>
<b>Relay 5</b>	<b>Fan2 Group</b>
<b>Relay 6</b>	<b>Fan3 Group</b>
<b>Relay 7</b>	<b>Fan4 Group</b>
<b>Relay 8</b>	<b>Fan5 Group</b>

### **Hidden function list**

Hidden Functions are functions are not found on the front panel function list and can be seen only after they are unlocked.

To unlock hidden function, follow these steps:

- A.** Go to the time function (function 01)
- B.** Push on “PROG”
- C.** Enter “3331” and then press "Enter".

Now the hidden functions will be unlocked and can be accessed.

59. Lock Code
60. Navg
61. Controller name
62. Digital inputs
63. Press Amp
64. Feed Mode
65. Protocol
66. Calib. Temp Sensor1
67. Calib. Temp Sensor2
68. Calib. Temp Sensor3
69. Calib. Temp Sensor4
70. Calib. Humidity Sensor
71. Version number