

## Vision Power Card Installation Reference



Program version:GAR143804E

U11 Chip Version: 31

### Digital Inputs

1	DAMPER 1 FEEDBACK	11	WATER COUNT
2	DAMPER 2 FEEDBACK	12	AUGER FEEDBACK
3	COOL CURTAIN FEEDBACK	13	
4		14	
5		15	
6		16	
7		17	RESET PANEL COMM. ALARM
8		18	
9	EGGS COUNTER – N50	19	AC POWER ALARM
10		20	SILO

### Analog Outputs 0 – 10 Volt

1		4	
2		5	
3		6	

### Temperature Sensors

1	TEMPERATURE SENSOR 1
2	TEMPERATURE SENSOR 2
3	TEMPERATURE SENSOR 3
4	TEMPERATURE SENSOR 4
5	TEMPERATURE SENSOR 5
6	TEMPERATURE SENSOR 6
7	OUT TEMPERATURE SENSOR

### Fast Analog Inputs

		DIP Switch Position			
		SW1		SW2	
		OFF	ON	OFF	ON
1F	FRONT HUMIDITY SENSOR		*	*	
2F	STATIC PRESSURE SENSOR		*	*	
3F	CO2 SENSOR		*	*	
4F	DAMPER 1 POTENTIOMETER	*		*	
5F	DAMPER 2 POTENTIOMETER	*		*	
6F	COOL CURTAIN POTENTIOMETER	*		*	
7F	REAR HUMIDITY SENSOR		*	*	
8F		*			*