




Motherboard V3.0 installation




Picture of new Motherboard V3.0 (with 32 Relays)



Picture of new Motherboard V3.0 (with 24 Relays)



Picture of new Motherboard V3.0 (with 16 Relays)



Picture of new Motherboard V3.0 (with 8 Relays)

Interface:



**Jumpers to
choose 1 Relay
configuration.**

110-230VAC

**Communication
lines to controller
(4 wires)**

**Emergency relay
Terminals**

**Communication
lines to
expansion box
(RS485)**

On bottom right there is 2 option to set first Relay configuration.

1. For main board put Jumper only on "Alarm Relay".
2. For Expansion board put Jumper only on "No Alarm Relay".