

## Vision Power Card Installation Reference



Program version:IFS199101E

U11 Chip Version: 34

### Digital Inputs

|    |  |    |                |
|----|--|----|----------------|
| 1  |  | 11 | WATER COUNT    |
| 2  |  | 12 | AUGER FEEDBACK |
| 3  |  | 13 |                |
| 4  |  | 14 |                |
| 5  |  | 15 |                |
| 6  |  | 16 |                |
| 7  |  | 17 |                |
| 8  |  | 18 |                |
| 9  |  | 19 | AC POWER ALARM |
| 10 |  | 20 | SILO           |

### Analog Outputs 0 – 10 Volt

|   |  |   |  |
|---|--|---|--|
| 1 |  | 4 |  |
| 2 |  | 5 |  |
| 3 |  | 6 |  |

### Temperature Sensors

|   |                        |
|---|------------------------|
| 1 | TEMPERATURE SENSOR 1   |
| 2 | TEMPERATURE SENSOR 2   |
| 3 | TEMPERATURE SENSOR 3   |
| 4 | TEMPERATURE SENSOR 4   |
| 5 |                        |
| 6 |                        |
| 7 | OUT TEMPERATURE SENSOR |

### Fast Analog Inputs

|    |                     | DIP Switch Position |    |     |    |
|----|---------------------|---------------------|----|-----|----|
|    |                     | SW1                 |    | SW2 |    |
|    |                     | OFF                 | ON | OFF | ON |
| 1F | HUMIDITY SENSOR     |                     | *  | *   |    |
| 2F | LIGHT SENSOR        | *                   |    |     | *  |
| 3F | FLAP 1 POT FEEDBACK | *                   |    | *   |    |
| 4F | FLAP 2 POT FEEDBACK | *                   |    | *   |    |
| 5F | FLAP 3 POT FEEDBACK | *                   |    | *   |    |
| 6F | FLAP 4 POT FEEDBACK | *                   |    | *   |    |
| 7F | FLAP 5 POT FEEDBACK | *                   |    | *   |    |
| 8F | CO2 SENSOR          |                     | *  | *   |    |